



Wooden Staircase

WSI0422

Please take time to become familiar with the parts as set out on the part identification sheet.

To assemble the model you will require the following:


- Good quality PVA
- Emery board or fine sandpaper
- Tweezers or similar to help locate small parts

1



Combine parts 1 and 2 as above taking care that everything aligns correctly.

2



Fix part 3 to the outside of both of the previous. Again be sure that everything aligns correctly.

3




Fix part 4.

4




Bring the two halves together as above.

5




Fix part 5 taking care that the assembly is kept square.

6




Fix part 6.

7



Fix in place the risers (part 7).

8



Fix the treads (parts 10.) noting tread above the middle landing is part no.8 and the bottom tread is part no. 9.

9




Add newel posts (part no. 11).

10



Add the base as shown (part no. 12). This will form a sound base when planting the model. It will also counter any bow that may occur in the legs.

11



Finally add the leg braces (part no. 13).

12



Enjoy your model !